



CourseName: Computer Vision Lab

Course Code: CSP-422

# **Experiment-3.1**

AIM- Write a program to determine the effectiveness of incorporating optical flow analysis into object tracking algorithms.

SOFTWARE REQUIRED: Any Python IDE (e.g., PyCharm, Jupyter Notebook, Google Colab)

RELEVANCE OF THE EXPERIMENT: This experiment aims to assess the effectiveness of incorporating optical flow analysis into object tracking algorithms. Optical flow analysis is a computer vision technique that estimates the motion of objects in a sequence of images. By integrating optical flow analysis into object tracking algorithms, we can enhance the accuracy and robustness of tracking moving objects in videos or real-time camera feeds. This experiment helps in understanding the impact of optical flow analysis on object tracking and provides insights into its potential applications in various fields such as surveillance, robotics, and augmented reality. Experiment aims to assess the effectiveness of incorporating optical flow analysis into object tracking algorithms. Optical flow analysis is a computer vision technique that estimates the motion of objects in a sequence of images. By integrating optical flow analysis into object tracking algorithms, we can enhance the accuracy and robustness of tracking moving objects in videos or real-time camera feeds. This experiment helps in understanding the impact of optical flow analysis on object tracking and provides insights into its potential applications in various fields such as surveillance, robotics, and augmented reality.

### **DESCRIPTION:**

Optical flow analysis is commonly integrated into object tracking algorithms to estimate the motion of objects in a sequence of frames. By leveraging optical flow, object tracking algorithms can track objects across frames and estimate their movement accurately. Optical flow analysis is typically incorporated into object tracking algorithms in following manner:

- 1. Optical Flow Estimation: Optical flow estimation calculates the dense motion vectors representing the apparent motion of pixels between consecutive frames. This can be achieved using various techniques, such as Lucas-Kanade, Horn-Schunck, or more advanced approaches like FlowNet or PWC-Net. Optical flow provides a per-pixel displacement field, indicating the direction and magnitude of motion.
- 2. Feature Selection and Tracking Initialization: Object tracking algorithms typically rely on key features or points to track objects. Using the optical flow field, salient features or points of interest are selected, such as corners or





Course Code: CSP-422

CourseName: Computer Vision Lab

distinctive regions, in the initial frame. These features serve as tracking targets, and their motion is estimated using optical flow.

- 3. Motion Estimation and Propagation: Once the initial features are selected, their motion vectors obtained from the optical flow field are used to estimate the overall motion of the tracked object. This can involve various methods, such as averaging the motion vectors or estimating a dominant motion direction. The estimated motion is then propagated to subsequent frames.
- 4. Feature Tracking and Updating: In each subsequent frame, the selected features are tracked by searching for their corresponding positions based on the estimated motion from the previous frame's optical flow. The features' positions are updated, and their motion vectors are re-estimated using optical flow analysis. This allows the algorithm to track the object's movement over time.
- 5. Occlusion Handling and Re-detection: Optical flow-based tracking algorithms need to handle occlusions where objects may be partially or fully hidden by other objects. Techniques such as motion segmentation or appearance modeling can be employed to handle occlusions and ensure accurate object tracking. If an object is completely lost or occluded, re-detection techniques can be used to re-initialize the tracking process.
- 6. Robustness and Adaptation: Object tracking algorithms utilizing optical flow often incorporate mechanisms to handle challenges such as illumination changes, scale variations, or camera motion. These can include adaptive parameter settings, feature selection strategies, or online model updates to ensure robust and accurate tracking performance.

#### **STEPS**

- 1. Read the input video or capture frames from a camera feed.
- 2. Initialize an object tracker using a suitable algorithm, such as the correlation-based tracker or the Kalman filter.
- 3. Iterate through each frame in the video sequence:
- a. Perform optical flow analysis on the current frame and the previous frame to estimate the motion vectors of key points or regions.
- b. Update the object tracker with the new frame and motion information.
- c. Draw bounding boxes around the tracked objects in the frame.
- d. Display the frame with the tracked objects.
- 4. Calculate the tracking accuracy by comparing the tracked object's position with the ground truth data, if available.
- 5. Evaluate the performance of the object tracking algorithm with and without incorporating optical flow analysis by analyzing the tracking accuracy, robustness, and computational efficiency.





Course Name: Computer Vision Lab Course Code: CSP-422

### **Implementation:**

```
import cv2
import numpy as np
# Step 1: Load a video or camera feed
# Replace 'video_path' with the path to your video file or use '0' for the default camera.
video_path = 'D:/New_folder/ComputerVision/video/GENERAL_SA_AERIAL_00190_preview.mp4'
cap = cv2.VideoCapture(video path)
# Step 2: Initialize the object tracker (e.g., using OpenCV's built-in tracker)
tracker = cv2.TrackerCSRT_create()
# Step 3: Initialize variables for performance evaluation
frame count = 0
success_count = 0
# Step 4: Loop through frames and perform object tracking
while True:
  ret, frame = cap.read()
  if not ret:
    break
 frame_count += 1
 if frame_count == 1:
    # Initialize the tracker with the first frame and bounding box
    bbox = cv2.selectROI('Select Object to Track', frame)
    tracker.init(frame, bbox)
 # Update the tracker with the current frame
```



Course Code: CSP-422 CourseName: Computer Vision Lab success, bbox = tracker.update(frame) if success: success\_count += 1 # Draw the bounding box on the frame (x, y, w, h) = tuple(map(int, bbox)) cv2.rectangle(frame, (x, y), (x + w, y + h), (0, 255, 0), 2)# Display the frame cv2.imshow('Object Tracking', frame) # Press 'q' to exit the loop if cv2.waitKey(1) & 0xFF == ord('q'): break # Step 5: Calculate and print the tracking success rate tracking\_success\_rate = (success\_count / frame\_count) \* 100 print(f"Tracking Success Rate: {tracking\_success\_rate:.2f}%") # Step 6: Release the video capture and close all windows cap.release()

## **Output:**

cv2.destroyAllWindows()

Tracking Success Rate: 100.00%



CourseName: Computer Vision Lab Course Code: CSP-422



